THE WOLFARD FLOWER BULB

Your Wolfard Flower Bulb may be used as either an oil candle or as a vase.

Filling: We include a filler spout with each Wolfard Flower Bulb to make filling easy. Simply attach the filler spout to your lamp oil bottle (it's designed to fit most standard one-quart oil bottles). Insert the flexible tip of the filler spout into the opening in the top of the lamp. Take care not to fill more than ¼" from the top, otherwise, oil may overflow when the wickholder is inserted. Insert the wickholder and wait for several minutes to allow the wick to fully absorb the lamp oil before lighting.

Lighting: The easiest way to light your Wolfard Flower Bulb Lamp is with a long-tip butane fireplace lighter or a long fireplace match, just avoid tilting the lamp during lighting, since this could cause fuel to spill.

Adjusting the Flame: When properly adjusted, your flame should be just about the size and intensity of a candle's. You can adjust the flame by raising or lowering the wick in its glass holder - but be sure to let the wick, wick holder and reservoir cool down before touching!

The top of the wick should be just below the lip of the glass wick holder. If any part of the wick, including threads or frays, protrudes from the top of the holder, your lamp may smoke. During initial use, or when refilling or sampling oils, watch the lamp for 15 minutes to make sure it doesn't smoke. If it does, blow out the flame, allow the lamp to cool, remove the wick holder from the lamp and pull the wick lower down into its holder.

Choosing Lamp Oil: We recommend Wolfard Lamp Oil because of its clean-burning qualities. If you can't find Wolfard Lamp Oil, any high quality lamp oil, including colored or scented oils, will do. Avoid using kerosene or cheap lamp oils, since they tend to smoke and have strong odors. Do not use solvents or fuels with lower ignition points than kerosene – such as alcohol, gasoline, paint thinner, or acetone - these are unsafe!

Cleaning: Because it's made from the finest heat-resistant glass available, your Wolfard Flower Bulb is rugged enough to be cleaned in the dishwasher. For best results, place lamp upside down so the reservoir doesn't fill with soap and water. Just remember that any object made of glass isn't indestructible, so treat your lamp with reasonable care. Thorough washing and drying is recommended when switching between vase and oil candle use. Make sure it is completely dry inside before filling with lamp oil otherwise the moisture will cause a crackling or popping noise while the flame is burning.

Using the Flower Bulb in a drafty area or outside may cause the flame to get PUFFY and smoke. Shielding the flame from the draft will help minimize this.

		APPROXIMATE
SIZE	FUEL CAPACITY	BURN TIME
Small	3 ounces	18 hours
Medium	4.5 ounces	26 hours
Large	5 ounces	30 hours

ALWAYS keep out of the reach of children whether lit or not. NEVER leave any device unattended while lit.

